

GRC838



INCREASE UP-TRAVEL:

1. Make sure tray height is set at the height you like.
2. Use tool GRC838 to hold DT1210
3. Screw in ST1236 x number of turns
4. Remove tool GRC838
5. Screw out ST1236 the same number of turns from step 3.
This will return tray height to starting point.
6. The DT1210 has been raised and up-travel increased.

DECREASE UP-TRAVEL

1. Make sure tray height is set at the height you like
2. Screw in ST1236 x number of turns.
3. Use tool GRC838 to hold DT1210
4. Screw out ST1236 the same x number of turns from step 2.
This will return tray height to starting point.
5. Remove tool GRC838
6. The DT1210 has been lowered on ST1236 and up-travel decreased.